



Spare Wire

A dashed red line labeled 'Spare Wire' connects the '12VDC Rail' terminal to the '+' terminal of the 'Optional 12VDC Auxiliary Power Supply'.

